



Zusatz zur Bedienungsanleitung

AE 540

Economy Version ohne DTMF Tastatur

Dieses Funkgerät verfügt nicht über die in der Anleitung beschriebene DTMF Tastatur am Mikrofon.

Entgegen den Angaben in der Bedienungsanleitung (Seite 7) ist wegen der nicht vorhandenen Tastatur auch keine direkte Frequenzeingabe möglich.

Das Gerät kann nicht als Option mit einer zusätzlichen DTMF Platine ausgestattet werden, da es keine DTMF Funktionen nutzen kann. Eine CTCSS Platine ist jedoch einbaubar und arbeitet wie in der Anleitung beschrieben.

Bitte beachten: Nur das mitgelieferte Mikrofon ohne Zehnertastatur kann bei dieser Version direkt angeschlossen werden. Soll ein DTMF Mikrofon benutzt werden, so muss das Gerät durch Umlöten interner Widerstandsbrücken von einer autorisierten Servicewerkstatt vorher adaptiert werden.

Important user informations

AE 540

Economy version without DTMF keyboard

This radio is not equipped with the DTMF keyboard microphone described in the user manual and cannot be operated with DTMF functions.

The direct keyboard frequency entry described on page 7 of the user manual is not possible, as well as no DTMF optional board can be installed, but installation of an optional CTCSS board is possible.

Note: This radio version can only be operated with the microphone shipped with this radio. Plug-and-play replacing by a DTMF keyboard microphone is not possible, because internal soldered jumper settings must be modified by an authorised service technician before.