


Operation Control



CE06810

- (1) Antenna
- (2) Monitor Key
- (3) Volume Control, On/Off [VOLUME / OFF]
- (4) Call Tone Key [CALL]
- (5) Push to Talk Key [PTT]
- (6) Channel Selector Key [▲]
- (7) Channel Selector Key [▼]
- (8) External Speaker Microphone Connection
- (9) LED Channel Display 1-8
- (10) Loudspeaker
- (11) Microphone
- (12) Battery Compartment & Belt Clip

MANUAL



Public Mobile Radio 446 Messenger

English 1

Setting up the TEAM Messenger

Inserting the Battery

The battery compartment lid (12), on the backside of the unit, can be opened by pressing the battery door at the marked area [IIII] and sliding it down. Then open the lid by lifting first the unlocked side. Insert now 3 batteries of the type AA. You can use either alkaline cells or rechargeable cells. Follow the polarity sign of the battery compartment. To close the battery compartment insert first the hooks of the lid into the holes of the upper side of the battery compartment. Then press the lid onto the compartment while you push the latch on it until it clicks into place.

Operating of the TEAM Messenger

After the batteries are inserted, radio operation can be undertaken.

1. Switching ON : [VOLUME / OFF]

Rotate the volume knob (3) [VOLUME / OFF] clockwise to turn the transceiver on. Adjust the volume control to an intermediate position. The radio works on the frequency 446,00625 MHz (= channel 1). Now the set is in receiving mode. In this mode the number of the actual channel disappears after 4 seconds and only a blinking dot is visible at the display.

2. Automatic squelch : [MONI]

The transceiver has a built-in automatic squelch which automatically mutes any noise when there is no signal on the channel. When you receive a transmission, the loudspeaker (10) is switching on and the red indicator lamp is alight in the channel display (9) . If you want to turn on the receiver audio path when the squelch is closed, press and hold the button (2) [MONI]. This disables the automatic squelch and the indicator lamp in the channel display lights up. Release the (2) [MONI] key to terminate the monitor function.

3. Channel Selection [▲ ▼]

All 8 channels can be selected by depressing the channel selector buttons [▲] (6) or [▼] (7) to the desired channel. The channel number will be displayed in the LED window (9) for 4 Seconds.

4. Transmit : [PTT]

To transmit, press and hold the (5) [PTT] button on the left hand side of the unit. During transmission the actual channel will be displayed. Then speak

DECLARATION OF CONFORMITY



We hereby declare that the product:

**PMR handheld transceiver
(8 Channels FM)**

Messenger

satisfies all the technical regulations applicable to the product within the scope of Council Directives and European standards:

CE06810

73/23/EEC, 89/336/EEC and 99/5/EC

ETS 300 296 (12/94)

ETS 300 279 (02/99), EN 50081-1, EN 50082-1

EN 60950:1992

Notified body involved: ETS Certification GmbH; ID-Nr. 0681

All essential radio test suites have been carried out.

The unit can be used without license and charges in:
A, B, CH, D, DK, E, F, FIN; GB, I, NL, S

Manufacturer:
TEAM Electronic GmbH
Bolongostr. 88
D-65929 Frankfurt/M.

This declaration is issued under the sole responsibility of the manufacturer.
Place and date of issue:

Frankfurt/M., 31. August 2000

B. Reimann
(Signature)
B. Reimann

TEAM Electronic GmbH

English 2

slowly in a normal tone of voice into the microphone (11) at a distance of 2 - 4 inches from your mouth. Speaking too loudly will cause distortion and make the signal difficult to understand. On completion of the transmission, release the PTT key and the unit will revert to receiving mode and the blinking dot is shown in the channel display.

5. Paging : [CALL]

To page another user, press the key (4) [CALL] for a few seconds. Your transceiver transmits with an audible tone, and the actual channel number lights up. A transceiver working on the same channel will receive the audible tone. While the tone is sent, no speech can be transmitted.

6. Key Lock

Select a channel and wait until the red dot appears. Now, press and hold the button (6) [▲] for 1 second, before, in addition, you press the button (7) [▼]. Hold both buttons for approximately 5 seconds until the red dot appears. A red, blinking bar indicates that the key lock function is activated.

To resume, repeat the aforementioned instructions. Once the red blinking bar disappears, the key lock function is deactivated.

7. Service for the TEAM Messenger :

The condition of the batteries must be tested from time to time. Worn out batteries must be removed from the unit immediately. They can leak and damage the device. The batteries should always be replaced as a complete set. Independent repairs or adjustments must not be carried out. In the event a defect becoming apparent, contact a properly equipped and authorised TEAM dealer or TEAM directly.

Conformity

The handheld transceiver TEAM Messenger is conforming to the European R&TTE Directive and meets the European Telecommunication Standards ETS 300 296 & ETS 300 279.

The product is meant for distribution in the following countries :

• Austria • Belgium • Denmark • Finland • France • Germany
• Great Britain • Italy • Netherlands • Spain • Sweden • Switzerland

• additional accessories

ORM-MS

Rüsselmikrofon mit Ohrhörerbügel • Boam microphone with earphone and earpiece • Combiné casque / micro avec bras semiflexible • microfono / auricolare con archetto e gambo del microfono flessibile Art. - Nr. PR2014

OEM-MS

Ohrhörmikrofon mit Befestigungsclip • headset/microphone with clip • microfono auricolare con clip • oreillette avec microphone e clip de fixation Art. - Nr. PR2019



Akkus • rechargeable batteries • piles rechargeables • pile ricaricabili

NMH 800 mAh
Art. - Nr. AK7001

NMH 1600 mAh
Art. - Nr. AK7004



NMH 1300 mAh
Art. - Nr. AK7002



NMH 1800 mAh
Art. - Nr. AK7007

NMH 1900 mAh
Art. - Nr. AK7008



Bitte nur geeignete Original TEAM Zubehörteile verwenden.
Please use original TEAM accessories only.
N'utilisez que des accessoires TEAM originaux, s'il vous plaît!
Solamente utilizzare degli accessori TEAM originali, per favore!

